

9", 21" AND COMBO GARDEN DEBRIS RAKE ASSEMBLY AND PARTS LIST

INSTRUCTIONS

1. Insert end of rake handle with pre-drilled holes into the neck of the 9" or 21" rake head.
2. Align holes of rake and handle and insert the included bolt.
3. Fasten bolt with the included nylon locknut on the back; twist until handle is secure.

