

1. To attach your assembled Harvester to your vehicle, pull vehicle up to within a few inches from the push frame assembly as shown.

*Note: Standard Golf does not manufacture or sell cart brackets. Contact your cart manufacturer for more information.*



Universal



Yamaha



Kubota



EZ GO/Cushman



John Deere



Club Car

2. Place bolt through the push frame assembly with washer as shown. Tighten nut on the back side until snug, then "back off" nut one quarter turn to allow the Harvester to pivot independently from the vehicle.



3. Your Standard Golf Harvester is now ready for use.

